



INSTRUCȚIUNI DE MONTAJ TRAMBULINĂ AGA SPORT PRO

AGA PRO(5FT,6FT,7FT,8FT,9FT,10FT,11FT,12FT,13FT,14FT,15FT,16FT,17FT,)



TRAMBULINĂ													
DENUMIRE ELEMENT	5 ft	6 ft	7 ft	8 ft	9 ft	10 ft	11 ft	12 ft	13 ft	14 ft	15 ft	16 ft	17 ft
	150 cm	180 cm	220 cm	250 cm	275 cm	305 cm	335 cm	366 cm	400 cm	430 cm	460 cm	500 cm	518 cm
A. BARĂ CADRU	6	6	6	6	6	6	8	8	12	12	12	12	12
B. PROTECȚIE ARCURI	1	1	1	1	1	1	1	1	1	1	1	1	1
C. SUPRAFAȚĂ DE SĂRIT	1	1	1	1	1	1	1	1	1	1	1	1	1
D. ARCURI	30	36	42	48	54	60	64	72	84	96	108	108	108
E. EXTENSIE PICIOR	0	0	0	6	6	6	8	8	12	12	12	12	12
F. PICIOR ÎN FORMĂ DE U	3	3	3	3	3	3	4	4	6	6	6	6	6
G. ȘURUBURI	0	0	0	0	0	0	0	0	12	12	0	0	0
H. UNEALTĂ MONTARE ARCURI	1	1	1	1	1	1	1	1	1	1	1	1	1



Denumire unelte	DIAMETRU TRAMBULINĂ													
	5 ft 150 cm	6 ft 180 cm	7 ft 220 cm	8 ft 250 cm	9 ft 275 cm	10 ft 305 cm	11 ft 335 cm	12 ft 366 cm	13 ft 400 cm	14 ft 430 cm	15 ft 460 cm	16 ft 500 cm	17 ft 518 cm	
A – Cheie reglablă	12	12	12	12	12	12	16	16	12	12	24	24	24	
B – Cheie stelată	1	1	1	1	1	1	1	1	1	1	1	1	1	
C – Plasă protecție	1	1	1	1	1	1	1	1	1	1	1	1	1	
D – Bară superioară	6	6	6	6	6	6	8	8	6	6	12	12	12	
E – Bară inferioară	6	6	6	6	6	6	8	8	6	6	12	12	12	

